

KLB-SYSTEM

AC-Härterpulver

Reactive catalyst for curing PMMA resins

Packaging units

| Article no. | Packaging | Content (kg) | Units/pallet |
|-------------|---------------|--------------|--------------|
| MA9999-96 | Can | 0.40 | 240 |
| MA9999-25 | Cardboard box | 25.00 | 24 |
| MA9999-70 | Cardboard box | 5.00 | 24 |

Product description

KLB-SYSTEM AC-Härterpulver is used to cure acrylic resins. To achieve optimal properties, the additive quantities recommended for the resins must be observed.

Product features

- · cures at low temperatures
- short curing times

Mixing

The addition of hardener compound varies from one acrylic resin to another. At higher temperatures, the amount of hardener should be reduced to a minimum, at low temperatures it should be increased up to the maximum amount of hardener. The average quantity indicated is recommended for room temperature. The amount of hardener specified must always be adhered to since amounts that are too small lead to hardener defects and amounts that are too large lead to discolouration. When mixing, add the hardener compound to the base component and mix thoroughly with a machine. Mix for at least 30 - 60 seconds and

then check that the hardener compound has dissolved completely. The resin mixed with the hardener compound is then added to the respective aggregate and blended till homogeneous.

Special remarks

Acrylic resins are sometimes supplied without hardener compound. If necessary, please order the recommended amount of hardener!



Please consider the latest version of this product information on our website.

All stated information is based on our experience and technical preparation. We guarantee the correct and proper quality of our products. We do not assume any responsibility for the work not carried out by us, since we have no influence on the processing or processing conditions. We recommend on-site trials to be conducted. With appearance of this new KLB product information, all prior information loses validity. The updated version is available on our website www.klb-koetztal.com. In addition, our "General Terms and Conditions" apply.



Günztalstraße 25 89335 Ichenhausen, GERMANY Phone +49 (0) 8223-96 92-0 Fax +49 (0) 8223-96 92-100 www.klb-koetztal.com info@klb-koetztal.com